

Anziehvorschrift Zylinderkopf

Tightening Instructions for Cylinder Head

Instructions de serrage pour culasse

Prescripciones de apriete para culatas

824.917


passend für / suitable for
adaptable à / adaptable a

Audi




Das Original

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



819.867
M 11 x 98



Anziehen/
Tightening/
Serrage/
Apriete

- 50 Nm
- 70 Nm
- 90 Nm
- 80°C
- 90 Nm
- 1.000 km
- 90 Nm

Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø 78,5, 2 Löcher/Holes

Mot. CN, 5 Cyl. 2,0 l Diesel, 51,5 kW

(70 PS)bis Chassis 43 B 077978>

D 20, 50 kW (68 PS), 3/1979>7/1981

Audi 100 D Avant, Audi 5000 (USA)

Elring-Serviceteam

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

24/01/22

824.917